


Update Instructions

Updating the firmware is performed using the built-in web server. Refer to the instructions below.


Requirements:

- AT-OME-SR21
 - Firmware file
 - Computer running Microsoft Windows
1. Connect an Ethernet cable from the computer, containing the firmware, to the same network where the AT-OME-SR21 is connected.
 2. Go to the **System** page in the web server.



The screenshot shows the AT-OME-SR21 System web interface. The top navigation bar includes links for Info, Video, Audio, Display, RS-232, EDID, USB, Config, System, and HDBT. The main content area is divided into three sections: Relay, Network, and System. The Relay section has controls for Relay 1 and Relay 2. The Network section shows MAC Address, IP Mode, IP, Netmask, Gateway, Telnet Port, Telnet Login Mode, Telnet Timeout, and Hostname. The System section includes Front Panel Lock, Reset to Default, Factory Default, Firmware Update, and Velocity Update. An orange callout box with the text "Choose File button" points to the "Choose File" button in the Firmware Update section.


3. Click the **Choose File** button, under **Firmware Update**.
4. Browse to the location of the firmware file, select it, and click the **Open** button.
5. Click the **Update** button, under the **Firmware Update** section.
6. The following message box will be displayed.



The screenshot shows a confirmation dialog box with the title "10.0.1.107 says:". The message inside the box is "Are you Sure want to update Firmware?". At the bottom of the box are two buttons: "OK" and "Cancel".

Update Instructions

6. Click the **OK** button to begin the firmware update process. Click the **Cancel** button to cancel the process.
7. After the firmware update process is complete, the **Login** screen will be displayed.



The screenshot shows the AT-OME-SR21 Login screen. At the top left is the ATLONA logo with the tagline 'Connecting Technology'. To its right is the text 'AT-OME-SR21 Login'. Below this is a dark horizontal bar. The main area is white and contains a login form titled 'Login' in a small box. The form has two input fields: 'Username' and 'Password', followed by a 'Submit' button.

8. The firmware update process is complete.