

## Release Notes

---

### Public Release

Firmware updating must be done using the Dante Firmware Update Manager found at: <https://www.audinate.com/products/firmware-update-manager>.

#### Version 1.0.01

Features	<ul style="list-style-type: none"><li>• N/A</li></ul>
Bug Fixes	<ul style="list-style-type: none"><li>• Static IP assignment now compatible with Dante Controller software.</li></ul>
Known Issues	<ul style="list-style-type: none"><li>• N/A</li></ul>

### Previous Releases

#### Version 1

- Factory Firmware