

AT-GAIN-NET UPDATE

Firmware Installation

Dante Firmware Update Manager User Guide available at, https://www.audinate.com/system/files/release/AUD-MAN-Firmware_Update_Manager-v2.7.pdf

For firmware update, the Dante card and host PC running the *Dante Firmware Update Manager*, must be on the same network segment.


1. Download *Dante Firmware Update Manager* at <https://www.audinate.com/products/firmware-update-manager>.
2. Open the *Dante Firmware Update Manager*, and select the interface being used to communicate with the Dante network audio card.




3. Select *Update Firmware* mode.



4. Browse to the Dante firmware file to be loaded, then hit *Next*.



5. The *Dante Firmware Update Manager* will now present you with discovered devices. Select the device you want to update and hit *Start*. If no devices are found, you enable *Override Device Matching*, in previous step.



When firmware update is complete, the following message will be prompted.

