

# Release Notes

---

## Public Release

Version 1.2.6	
Features	<ul style="list-style-type: none"> <li>Added the Blink command, which will enable blinking of the <b>PCM</b> LED indicator, and is useful for physically locating the unit on a network.</li> <li>Added firmware verification process, preventing invalid or corrupt firmware from being uploaded.</li> <li>Added Reboot command, which allows the unit to be power-cycled. All configuration information is retained.</li> <li>A “black frame” is sent on the output if no source device is not connected to the unit. This feature can be disabled using the FreeRunSW command with the off parameter. Refer to the User Manual for more information on this command.</li> </ul>
Bug Fixes	<ul style="list-style-type: none"> <li>Fixed an issue where an incorrect internal EDID is selected when connected to a DVI monitor.</li> <li>Fixed an issue where the VOLMute1 command caused the unit to lockup.</li> <li>Fixed an issue where the volume would change when a source device is connected.</li> <li>Fixed an issue where an audible “pop” is heard, if the audio level of the unit is set to higher than 0 dB (an uncommon situation).</li> <li>Fixed an issue where the DHCP lease was not being renewed.</li> <li>Improved Telnet command response time.</li> <li>Improved DSP control; audio delay is near 1 second.</li> </ul>
Known Issues	<ul style="list-style-type: none"> <li>N/A</li> </ul>

## Previous Releases

Version 1.1.00	
	<ul style="list-style-type: none"> <li>Factory Firmware</li> </ul>