

Update Instructions


Requirements:

- AT-USB-EX100-TX
- AT-USB-EX100-RX
- Firmware file
- Computer running Windows
- USB-A to USB micro-B cable



IMPORTANT: The AT-USB-EX100-KIT should be updated as a kit, and the TX and RX should be connected via their HDBaseT connectors prior to the firmware update.

1. Disconnect power from the AT-USB-EX100-TX.
2. Connect a USB-A to USB micro-B cable between the PC and the **FW** port on the AT-USB-EX100-TX.
3. Reconnect power to the AT-USB-EX100-TX and AT-USB-EX100-RX.
4. Connect an HDBaseT cable from the **HDBaseT OUT** port on the transmitter to the **HDBaseT IN** port on the receiver.
5. The **PWR** LED indicator on the AT-USB-EX100-TX will start flashing.
6. The USB UPDATE folder will be displayed. If this folder is not displayed, automatically, select the USB UPDATE drive from Windows Explorer.



7. Delete all files from the USB UPDATE drive, if any are present.
8. Drag-and-drop the firmware file to the drive.
9. The **PWR** LED indicator on the front panel will flash green while the unit is being updated. Do not disconnect the USB cable during the update process. When the **PWR** LED stops flashing and is solid green, the update process will be complete.
10. Disconnect the USB cable from the unit.
11. The firmware update process is complete.