

## Release Notes

---

### Beta Release

Version 2.0.26	
Features	<ul style="list-style-type: none"> <li>Added the ability to momentarily pulse the relays instead of using a constant latch. Use the RelayPulseTime y command, where y is 1-30 seconds.</li> </ul>
Bug Fixes	<ul style="list-style-type: none"> <li>Improved interoperability with the AT-HDVS-210H-TX-WP and AT-HDVS-210U-TX-WP.</li> <li>Resolved an issue where a scrambled A/V signal would be displayed, if HDCP content was sent to a non-HDCP sink.</li> <li>Fixed an issue where if the source was connected during the lamp cool down period, the system would turn on.</li> </ul>
Known Issues	<ul style="list-style-type: none"> <li>None at this time</li> </ul>

### Public Release

Version 2.0.00	
Features	<ul style="list-style-type: none"> <li>While in kitmode, the output volume can be controlled from the HDVS-200-RX</li> <li>Added mDNS functionality</li> </ul>
Bug Fixes	<ul style="list-style-type: none"> <li>Improved integrity of video output over long durations (&lt; 24 hours)</li> <li>Modification of the root account, by the root user, no longer causes login problems</li> <li>Fixed an issue where the unit would not send the hex character \$08</li> <li>Resolved issue where power-cycling some displays could cause loss of audio on the display</li> <li>Improved the reliability of the TrigRS232 and TrigCEC command</li> <li>DHCP lease time now functions correctly</li> <li>Resolved an issue where sending an input command, while in kitmode, could cause the unit to lock up</li> </ul>
Known Issues	<ul style="list-style-type: none"> <li>None at this time</li> </ul>

### Previous Release

Version 1.1.09	
Features	<ul style="list-style-type: none"> <li>None at this time</li> </ul>
Bug Fixes	<ul style="list-style-type: none"> <li>Now correctly changes the resolution of the output to the HDVS-200-TX's EDID when "Input is selected"</li> <li>Unit no longer loses audio on reboot while connected to an AT-UHD-SW-5000ED</li> <li>Now correctly passes RS-232 commands when connected to an AT-UHD-EX-100CE-TX</li> <li>Pressing display on/off on the HDVS-150-TX no longer crashes the 200-RX</li> <li>RX OSD now shows on the display when connected to an HDBaseT transmitter</li> </ul>
Known Issues	<ul style="list-style-type: none"> <li>None at this time</li> </ul>

## Release Notes

### Version 1.0.32

Features	<ul style="list-style-type: none"><li>• None at this time</li></ul>
Bug Fixes	<ul style="list-style-type: none"><li>• Resolved volume control issue with HDVS-150-TX</li><li>• CEC now functions correctly</li></ul>
Known Issues	<ul style="list-style-type: none"><li>• None at this time</li></ul>

### Version 1.0.16

Features	<ul style="list-style-type: none"><li>• Added HDVS sta command</li></ul>
Bug Fixes	<ul style="list-style-type: none"><li>• Improved IP communication to device</li><li>• Changed the default baud rate of the RS232 ports to 115200 for standardization</li><li>• Relay is now controlled properly over IP</li><li>• Resolved issue changing the parity via CLI</li><li>• Now correctly pulls the resolution from the input device (when used with HDVS-200-TX) when using the 'Input' option in the webGUI 's video page</li></ul>
Known Issues	<ul style="list-style-type: none"><li>• None at this time</li></ul>

### Version 1

<ul style="list-style-type: none"><li>• Factory Firmware</li></ul>
--