

Update Instructions

Requirements:


- AT-OME-EX-TX-LT
- AT-OME-EX-RX-LT
- Firmware file
- Computer running Windows
- USB-A to micro-USB cable

1. Disconnect power from the AT-OME-EX-TX-LT.
2. Make sure the AT-OME-EX-TX-LT and AT-OME-EX-RX-LT are connected to the **HDBaseT** ports using a category (CAT-5e or better) cable.



IMPORTANT: Both units must be connected to apply the firmware update to both the AT-OME-EX-TX-LT and AT-OME-EX-RX-LT. The update process can take up to five minutes to complete.

3. Connect a USB-A to micro-USB cable between the PC and the **FW** port on the AT-OME-EX-TX-LT (transmitter).
4. Power the AT-OME-EX-TX-LT.
5. The USB UPDATE folder will be displayed. If this folder is not displayed, automatically, select the USB UPDATE drive from Windows Explorer.



6. Delete all files from the USB UPDATE drive, if any are present.
7. Drag-and-drop the firmware file to the drive.
8. The **PWR** LED indicator, on the front panel, will flash green while the unit is being updated. Do not disconnect the USB cable during the update process. When the **PWR** LED stops flashing and is solid green, the update process will be complete.