


Update Instructions


Requirements:

- AT-OME-EX-TX
- AT-OME-EX-RX
- Firmware file
- Computer running Windows
- USB-A to USB mini-B cable
- USB Firmware Update Tool

1. Disconnect power from the unit.
2. Connect a USB-A to USB mini-B cable between the computer and the **FW** port on the unit. Either the TX or RX can be updated first.




3. Power the unit. If updating the AT-OME-EX-TX, then make sure the receiver is powered using the included power supply or a category cable is connected between the HDBaseT ports of both the transmitter and receiver units.
4. If a USB UPDATE folder is opened automatically, notate the drive letter and close the folder.
5. Launch the USB Update Tool.
6. The drive letter of the mounted drive for the unit will be displayed in the **Disk Drive** field. If it is not, click the **Refresh** button.



Update Instructions


- Click the **Browse** button and select the firmware file. Once the firmware file is selected, it will appear in the **Firmware File** field. If the firmware file is not displayed in this field, click the **Refresh** button.
- Click the **Update Firmware** button.



- The firmware update process will begin and will be monitored by a progress bar.




IMPORTANT: Do not disconnect power from the unit while performing the firmware update procedure.



Update Instructions

10. After the update process has completed, the `Copy process completed` message will be displayed in the message window.

The **PWR** LED indicator, on the front panel, will flash green while the unit is being updated. Do not disconnect the USB cable during the update process. When the **PWR** LED stops flashing and is solid green, the update process will be complete.



11. Repeat the above steps for each transmitter and receiver.