

Update Instructions


Updating the firmware is performed using the built-in web server.




IMPORTANT: The Valens firmware update cycle can take anywhere from 5 to 15 minutes to complete.

Requirements:

- AT-OME-MS42
 - Firmware file
 - Computer on the same network as the AT-OME-MS42
1. Download the firmware file from atlonac.com and extract the contents of the .zip file to a folder on the computer desktop.
 2. Connect an Ethernet cable from the computer, containing the firmware, to the same network where the AT-OME-MS42 is connected.
 3. Login to the built-in web server. Refer to the AT-OME-MS42 User Manual for details.
 4. Click **System** in the menu bar.




5. Click the **Choose File** button, under the **Firmware Update** section.
6. Browse to the location of the firmware file, select it, and click the **Open** button.
7. Click the **Update** button, under the **Firmware Update** section. The following message box will be displayed.



Update Instructions

- Click the **OK** button to begin the firmware update process. Click the **Cancel** button to cancel the process.
- After the firmware update process is complete, the **Login** screen will be displayed.



The screenshot shows the AT-OME-MS42 Login interface. At the top left is the ATLONA logo (a stylized 'A' in a circle) and the text 'ATLONA a PANOUT company'. To the right of the logo is the text 'AT-OME-MS42 Login'. Below this is a dark horizontal bar. The main content area is white and contains a central login form. The form has a title 'Login' in a small box. It includes two input fields: 'Username' and 'Password'. Below these fields is a 'Submit' button. At the bottom of the form is a 'Toggle HTTP/HTTPS' button.