



# Update Instructions

Requirements:

- AT-OME-PS62
  - Firmware file
  - Computer on the same network as the AT-OME-PS62
1. Connect an Ethernet cable from the computer, containing the firmware, to the same network where the AT-OME-PS62 is connected.
  2. Launch a web browser and enter the IP address of the AT-OME-PS62 in the address bar.
  3. Login to the web GUI, then click **System** in the menu bar, near the top of the screen.



4. Click the **Choose File** button, under the **Firmware Update** section.
5. Browse to the location of the firmware file, select it, and click the **Open** button.
6. Click the **Update** button, under the **Firmware Update** section.
7. The following message box will be displayed.



## Update Instructions

6. Click the **OK** button to begin the firmware update process. Click the **Cancel** button to cancel the process.
7. After the firmware update process is complete, the **Login** screen will be displayed.



The screenshot displays a web interface for the AT-OME-PS62 device. At the top left, the Atlona logo and 'a PANOUT company' are visible. To the right of the logo, the text 'AT-OME-PS62 Login' is displayed. The main area of the page is a large white rectangle containing a centered 'Login' dialog box. This dialog box has a title bar labeled 'Login' and contains two input fields: 'Username' and 'Password'. Below these fields is a 'Submit' button.