

Update Instructions

Updating the firmware can be completed using either the USB interface or the web GUI. Atlona recommends using the web GUI for updating the firmware. However, if a network connection is not available, the AT-UHD-SW-51 firmware can be updated using a USB-A to USB mini-B cable.

Using the Web GUI


Requirements

- AT-UHD-SW-51
 - Firmware file: UHDSW51_[version].BIN
 - Computer running Windows
1. Connect an Ethernet cable from the computer, containing the firmware, to the same network where the AT-UHD-SW-51 is connected.
 2. Launch a web browser and enter the IP address of the AT-UHD-SW-51 in the address bar.
 3. The **Login** screen will be displayed. Enter the login credentials. The default username and password are listed below:

Username	root
Password	Atlona



4. Click the **Login** button.
5. Click **Update** in the menu, near the top of the screen.



Update Instructions


- Click the **Browse...** button and select the UHDSW51_[version].BIN file.
- Click the **Upload** button to begin the firmware update procedure. The progress bar will show the current percentage of completion. Once the update is complete, the AT-UHD-SW-51 may display a prompt to restart the unit. Click OK to restart the unit.
- The firmware update is now complete and the switcher is ready to be used.

Using USB


Requirements

- AT-UHD-SW-51
- Firmware file: UHDSW51_[version].BIN
- Computer running Windows
- USB-A to USB mini-B cable

- Disconnect power from the AT-UHD-SW-51.
- Connect the USB-A to USB mini-B cable from the computer to the **FW** port on the rear panel of the AT-UHD-SW-51.




- Press and hold the **INPUT** key on the front panel, while connecting power to the AT-UHD-SW-51. *Continue to depress the INPUT key for five seconds after power is reconnected.*



- Release the **INPUT** key.
- The USB UPDATE folder will be displayed.

If this folder is not displayed, automatically, select the USB UPDATE drive from Windows Explorer.



Update Instructions

6. Delete all files from the USB UPDATE drive, if any are present.
7. Drag-and-drop the UHDSW51_[version].BIN firmware file to the USB drive.
8. After the file has been copied, disconnect the USB cable from both the computer and the AT-UHD-SW-51.
9. Power-cycle the AT-UHD-SW-51 by disconnecting then reconnecting the power supply.
10. The firmware update process is complete.