Update Instructions

Updating the firmware is performed using the built-in web server. Refer to the instructions below.

Requirements:

- AT-OME-SR21
- Firmware file
- Computer running Microsoft Windows

1. Connect an Ethernet cable from the computer, containing the firmware, to the same network where the AT-OME-SR21 is connected.
2. Go to the **System** page in the web server.

3. Click the **Choose File** button, under **Firmware Update**.
4. Browse to the location of the firmware file, select it, and click the **Open** button.
5. Click the **Update** button, under the **Firmware Update** section.
6. The following message box will be displayed.

Update Instructions

6. Click the **OK** button to begin the firmware update process. Click the **Cancel** button to cancel the process.
7. After the firmware update process is complete, the **Login** screen will be displayed.

8. The firmware update process is complete.