

## Release Notes

---

Version 1.3	Previous Function
<ul style="list-style-type: none"><li>Added volume ramping capability on analog audio outputs.</li></ul>	<ul style="list-style-type: none"><li>Only single button presses were accepted.</li></ul>
<ul style="list-style-type: none"><li>System mutes analog audio outputs when room is turned off.</li></ul>	<ul style="list-style-type: none"><li>When the room was turned off, the analog audio continued to output.</li></ul>
<ul style="list-style-type: none"><li>Added mute toggle command.</li></ul>	<ul style="list-style-type: none"><li>Only the discrete mute on and mute off commands existed.</li></ul>

## Release Notes

### Version 13

Features	<ul style="list-style-type: none"> <li>Added the ability to factory reset the matrix from the front panel.</li> <li>Added the ability to change the IPTimeout on the webGUI.</li> <li>Added VOUT status command.</li> <li>Added MirrorHdmi status command.</li> <li>Added Blink command for AMS support.</li> <li>Improved system stability.</li> <li>Labels now available for HDMI outputs.</li> <li>x#\$ command now supports on, off, and status.</li> <li>Increased IP connection speed when Broadcast is on.</li> <li>Routing command now accepts 0 as an input parameter - Command will work like x#\$ off.</li> </ul>
Bug Fixes	<ul style="list-style-type: none"> <li>Corrected EDID memory title to represent the copied display.</li> <li>System no longer locks up when the network becomes unstable.</li> <li>WebGUI page now reports HDCP correctly.</li> <li>Users now adding correctly through the webGUI.</li> <li>Baud rate now saves correctly through the webGUI.</li> <li>Fixed HDMI mirrored output following the wrong HDBaseT output.</li> <li>Audio now resetting to default when Mreset is used.</li> <li>Front panel now displaying EDID data correctly.</li> <li>Analog audio now passes when no receiver is connected to the corresponding HDBaseT port.</li> <li>Zone commands now passing Hex commands '00' and '0D' correctly.</li> <li>Copied EDIDs now saving properly.</li> <li>Humax IR codes no longer change input on the matrix.</li> <li>Discrete IR mute code now correctly toggles mute on AND off.</li> <li>Matrix now correctly routes output 5 command when selected from the IR remote.</li> </ul>
Known Issues	<ul style="list-style-type: none"> <li>None at this time</li> </ul>

### Version 1

- Factory Firmware