

Update Instructions

The AT-GAIN-60 can only be updated through the web GUI.



IMPORTANT: As of this writing, Google Chrome is the only browser that is supported for firmware updates. Other browsers will be supported in future versions of firmware.

Required items:


- Firmware
 - IP address of the AT-GAIN-60
 - Computer on the same network as the AT-GAIN-60
 - Username and password to access the web GUI
1. Verify that an Ethernet cable is connected between the AT-GAIN-60 and the network. The computer used to access the web GUI must be on the same network as the AT-GAIN-60.
 2. Type the IP address of the AT-GAIN-60 into the web browser, as shown in the example below.




3. The login screen will be displayed. Login using the username and password. The default login credentials are:

Username: admin

Password: Atlona



 **ATLONA**
Technical Support: US: 1 (877) 536-3976 International: 1 (408) 962-0515

AT-GAIN-60

Login

Username


Password

Login

Clear


Update Instructions

4. Click **Status** in the menu bar on left side of the screen.
5. Click the **Save** button.



The screenshot shows the ATLONA web interface. On the left is a navigation menu with 'Home', 'Settings', and 'Configuration'. The 'Settings' section is active, showing 'System Information' and 'System Settings'. The 'System Information' table lists Model (AT-GAIN-60), Firmware (1.0.00), MAC Address (B8:98:B0:11:11:11), Serial Number (9988776655443322998), and Operating Time (0000:00:46:10). The 'System Settings' section has an 'Upload File' field, a 'Status' dropdown, and 'Browse' and 'Load' buttons. A 'Download Log' button is also present in the System Information section.

6. The **Save As** dialog box will be displayed. Select the folder where the file will be saved. Click the **Save** button to save the file. The file is saved in .bin format and uses the default name of systemsettings.bin.
7. Click **Firmware** on the left side of the screen.



The screenshot shows the ATLONA web interface with the 'Firmware' section selected in the left menu. The 'Firmware Status' table shows Current Firmware (1.0.00). The 'Firmware Update' section has an 'Upload File' field, a 'Status' dropdown, and 'Browse' and 'Load' buttons.

8. Click the **Browse** button to select the firmware file.
9. Click the **Load** button to begin the upgrade process. Once the update has been completed, the login screen will be displayed.



WARNING: Power must not be disconnected or interrupted during the firmware update process.