


Update Instructions


Updating the firmware is performed using the built-in web server.

Requirements:

- AT-OME-MH21
 - Firmware file
 - Computer on the same network as the AT-OME-MH21
1. Download the firmware file from atlona.com and extract the contents of the .zip file to a folder on the computer desktop.
 2. Power on the unit and connect an Ethernet cable from the computer, containing the firmware, to the same network where the AT-OME-MH21 is connected.
 3. Login to the web server.
 4. Click **System** in the menu bar.




5. Click the **Choose File** button, under the **Firmware Update** section.
6. Browse to the location of the firmware file, select it, and click the **Open** button. Click the **Update** button, under the **Firmware Update** section. The following message box will be displayed.



Update Instructions

7. Click the **OK** button to begin the firmware update process. Click the **Cancel** button to cancel the process.
8. After the firmware update process is complete, the **Login** screen will be displayed.



The screenshot shows the login interface for the AT-OME-MH21 device. At the top left is the Atlona logo and text. To its right is the title "AT-OME-MH21 Login". The main area contains a login form with a title bar "Login". Inside the form, there are fields for "Username" (containing "admin") and "Password" (containing "*****"), followed by a "Submit" button. Below the form, the IP address "1.877.536.3976" is displayed, along with a link to "atlona.com" and another IP address "41.41.508.4121". At the bottom of the form area is a "Toggle HTTP/HTTPS" button.