


AT-HDVS-TX-WP-NB


The AT-HDVS-TX-WP-NB is a no-button face plate for US HDVS and HDVS-150 wall plate modules.

Note: HDVS and HDVS-150 purchased separately.




Remove the screws from the HDMI and VGA ports before removing the faceplate.

Once the screws are removed, pull the face plate off the back box. (see below)



Use a set of pliers to grab hold of the buttons, turn them slightly to the left as they are pulled off.



Once the buttons are removed, place the AT-HDVS-TX-WP-NB on the front of the HDVS wall plate and replace the screws. Installation is complete and the HDVS is ready to be used again.